


ENGINEERING
TOMORROW



Service Manual

Series 40 M46

Variable Pumps



Revision history*Table of revisions*

Date	Changed	Rev
September 2017	minor edit - displacement limiter torque	0202
June 2014	Danfoss layout - add HC EDC Control	BA
October 2010	corrections to port location illustration	AE
March 2010	Fix Osaka address	AD
March 2009	added spool alignment illustration	AC
May 2008	Fixed the illustrations	AB
October 2007	First edition	AA

Contents

Introduction

Overview.....	5
Warranty.....	5
General instructions.....	5
Remove the unit.....	5
Keep it clean.....	5
Replace all O-rings and gaskets.....	5
Safety precautions.....	5
Symbols used in Danfoss literature.....	6
Design.....	7
The system circuit.....	8
The basic closed circuit.....	8
Case drain and heat exchanger.....	8
Pump schematic.....	9

Fluid and filter maintenance

Fluid and filter recommendations.....	10
Hazardous material.....	10

Initial startup procedures

General	11
Start-up procedure.....	11

Required tools and pressure measurements

Required tools.....	12
Port locations and gauge installation.....	12

Troubleshooting

Overview.....	14
Safety precautions.....	14
System noise or vibration.....	14
System operating hot.....	14
System will not operate in one direction.....	15
System will not operate in either direction.....	15
Neutral difficult or impossible to find.....	16
System response is sluggish.....	16
Electrical troubleshooting.....	17

Adjustments

Standard procedures, inspections, and adjustments.....	18
Warranty.....	18
Pump adjustment.....	18
Charge pressure relief valve.....	18
Engaging the bypass function.....	19
System check/relief (SCR) valves.....	20
Displacement limiter adjustment.....	21
Swashplate neutral adjustment.....	22
Measured data.....	22
Pump Setup.....	22
Manual Displacement Control Neutral-Return Bracket Adjustment.....	23
Measured data.....	23
Procedure.....	23
Electric Displacement Control/Hydraulic Displacement Control Neutral Adjustment.....	24
Measured data.....	24
Procedure.....	24
HC EDC Control.....	25
Control neutral adjustment.....	25

Minor repair

Standard procedures, removing the pump.....	28
Displacement limiter.....	28
Pressure filtration adapter.....	29

Contents

Charge pump.....	30
Shaft seal, roller bearing and shaft replacement.....	32
SCR valves.....	33
Charge pressure relief valve.....	34
Bypass valve.....	35
Manual displacement control.....	36
Electronic displacement control/hydraulic displacement control.....	37
MDC orifice repair.....	39
EDC/HDC orifice repair.....	40
HC EDC Control Repair.....	41

Torque chart

Fastener size and torque chart.....	44
Plug size and torque chart.....	44

Introduction

Overview

This manual includes information for the installation, maintenance, and minor repair of the Series 40 M46 pump. It includes a description of the unit and its individual components, troubleshooting information, and minor repair procedures.

Performing minor repairs requires the unit to be removed from the vehicle/machine. Thoroughly clean the unit before beginning maintenance, or repair activities. Since dirt and contamination are the greatest enemies of any type of hydraulic equipment, follow cleanliness requirements strictly. This is especially important when changing the system filter and when removing hoses or plumbing.

A worldwide network of Danfoss Global Service Partners is available for major repairs. Danfoss trains Global Service Partners and certifies their facilities on a regular basis. You can locate your nearest Global Service Partner using the distributor locator at www.powersolutions.danfoss.com.

Warranty

Performing installation, maintenance, and minor repairs according to the procedures in this manual will not affect your warranty. Major repairs requiring the removal of a unit's front flange voids the warranty unless done by a Danfoss Global Service Partner.

General instructions

Follow these general procedures when repairing Series 40 M46 variable displacement closed circuit pumps.

Remove the unit



Prior to performing repairs, remove the unit from the vehicle/machine. Chock the wheels on the vehicle or lock the mechanism to inhibit movement. Be aware that hydraulic fluid may be under high pressure and/or hot. Inspect the outside of the pump and fittings for damage. Cap hoses and plug ports after removal to prevent contamination.

Keep it clean



Cleanliness is a primary means of assuring satisfactory pump life, on either new or repaired units. Clean the outside of the pump thoroughly before disassembly. Take care to avoid contamination of the system ports. Cleaning parts using a clean solvent wash and air drying is usually adequate.

As with any precision equipment, keep all parts free of foreign materials and chemicals. Protect all exposed sealing surfaces and open cavities from damage and foreign material. If left unattended, cover the pump with a protective layer of plastic.

Replace all O-rings and gaskets



Danfoss recommends you replace all O-rings, seals, and gaskets during repair. Lightly lubricate all O-rings with clean petroleum jelly prior to assembly.

Safety precautions

Always consider safety precautions before beginning a service procedure. Protect yourself and others from injury. Take the following general precautions whenever servicing a hydraulic system.

Introduction

Unintended machine movement

Warning

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable/disconnect the mechanism while servicing.

Flammable cleaning solvents

Warning

Some cleaning solvents are flammable. To avoid possible fire, do not use cleaning solvents in an area where a source of ignition may be present.

Fluid under pressure

Warning

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. This fluid may also be hot enough to cause burns. Use caution when dealing with hydraulic fluid under pressure. Relieve pressure in the system before removing hoses, fittings, gauges, or components. Never use your hand or any other body part to check for leaks in a pressurized line. Seek medical attention immediately if you are cut by hydraulic fluid.

Personal safety

Warning

Protect yourself from injury. Use proper safety equipment, including safety glasses, at all times.

Hazardous material

Warning

Hydraulic fluid contains hazardous material. Avoid prolonged contact with hydraulic fluid. Always dispose of used hydraulic fluid according to state, and federal environmental regulations.

Symbols used in Danfoss literature



WARNING may result in injury



CAUTION may result in damage to product or property



Reusable part



Non-reusable part, use a new part



Non-removable item



Option - either part may exist



Tip, helpful suggestion



Lubricate with hydraulic fluid



Apply grease / petroleum jelly



Apply locking compound



















Inspect for wear or damage



Clean area or part

Introduction

	Superseded - parts are not interchangeable		Be careful not to scratch or damage
	Measurement required		Note correct orientation
	Flatness specification		Mark orientation for reinstallation
	Parallelism specification		Torque specification
	External hex head		Press in - press fit
	Internal hex head		Pull out with tool – press fit
	Torx head		Cover splines with installation sleeve
	O-ring boss port		Pressure measurement/gauge location or specification

The symbols above appear in the illustrations and text of this manual. They are intended to communicate helpful information at the point where it is most useful to the reader. In most instances, the appearance of the symbol itself denotes its meaning. The legend above defines each symbol and explains its purpose.


Design

Danfoss Series 40 M46 closed-circuit axial-piston pumps convert input torque into hydraulic power. The input shaft transmits rotational force to the cylinder block. Bearings at the front and rear of the pump support the input shaft. Splines connect the cylinder block to the input shaft. A lip-seal at the front end of the pump prevents leakage where the shaft exits the pump housing. The spinning cylinder block contains seven reciprocating pistons. A ball joint connects a brass slipper to each piston. A spring washer and the force of charge pressure holds the slippers to the swashplate. The reciprocating movement of the pistons occurs as the slippers slide against the inclined swashplate during rotation. Via the valve plate, one half of the cylinder block connects to low pressure and the other half to high pressure. As each piston cycles in and out of its bore, fluid displaces from inlet to outlet imparting hydraulic power into the system. A small amount of fluid flows from the cylinder block/valve plate and slipper/swashplate interfaces for lubrication and cooling. The pump also uses excess flow from the charge pressure relief valve for cooling. Case drain ports return this fluid to the reservoir. A gerotor-style charge pump provides this flow and maintains a minimum pressure in the system loop.

The angle of the swashplate controls the volume of fluid displaced into the system. The servo piston sets swashplate angle. The pump control modulates servo piston position by varying differential pressure across the piston.

Introduction

Cross section view



The system circuit

The basic closed circuit


Hydraulic lines connect the main ports of the pump to the main ports of the motor. Fluid flows in either direction from the pump to the motor and back in this closed circuit. Either of the hydraulic lines can be under high pressure. In pumping mode the angle of the pump swashplate determines which line is high pressure as well as the direction of fluid flow.

Case drain and heat exchanger

The pump and motor require case drain lines to remove hot fluid from the system. The pump and motor should be drained from their top most drain port to ensure the case remains full of fluid. Flow from the motor case drain may route to the lower drain port on the pump housing and out the top most port, or feed directly to the heat exchanger. The system requires a heat exchanger with a bypass valve to cool the case drain fluid before it returns to the reservoir.


Introduction

System circuit diagram



Pump schematic

Pump schematic



Above schematic shows the function of a Series 40 M46 axial piston variable displacement pump.

Fluid and filter maintenance

Fluid and filter recommendations

To ensure optimum life, perform regular maintenance of the fluid and filter. Contaminated fluid is the main cause of unit failure. Take care to maintain fluid cleanliness when servicing.

Check the reservoir daily for proper fluid level, the presence of water, and rancid fluid odor. Fluid contaminated by water may appear cloudy or milky, or free water may settle in the bottom of the reservoir. Rancid odor indicates the fluid was exposed to excessive heat. Change the fluid immediately if these conditions occur. Correct the problem immediately. Inspect vehicle for leaks daily.

Change the fluid and filter per the vehicle/machine manufacturer's recommendations or at these intervals:

We recommend first fluid change at 500 hours.

Caution

High temperatures and pressures accelerate fluid aging. More frequent fluid changes may be required.

Change the fluid more frequently if it becomes contaminated with foreign matter (dirt, water, grease, etc.) or if the fluid is subjected to temperature levels greater than the recommended maximum.

Dispose of used hydraulic fluid properly. Never reuse hydraulic fluid.

Change filters whenever you change the fluid or when the filter indicator shows that it is necessary to change the filter. Replace all fluid lost during filter change.

Fluid and filter change interval

Reservoir type	Max oil change interval
Sealed	2000 hours
Breather	500 hours

Hazardous material

Warning

Hydraulic fluid contains hazardous material. Avoid contact with hydraulic fluid. Always dispose of used hydraulic fluid according to state, and federal environmental regulations.

Initial startup procedures

General

Follow this procedure when starting-up a new pump installation or when restarting an installation in which the pump was removed. Ensure pump is thoroughly tested on a test stand before installing.

Warning

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable/disconnect the mechanism while servicing.

Prior to installing the pump, inspect for shipping damage.

Start-up procedure

1. Ensure the machine hydraulic oil and system components (reservoir, hoses, valves, fittings, and heat exchanger) are clean and free of any foreign material.
2. Install new system filter element(s) if necessary. Check that inlet line fittings are properly tightened and there are no air leaks.
3. Install the pump. Install a 50 bar [1000 psi] gauge in the charge pressure gauge port M
4. Fill the housing by adding filtered oil in the upper case drain port. Replace plug.
5. Fill the reservoir with hydraulic fluid of the recommended type and viscosity. Use a 10-micron reservoir filler filter. Ensure inlet line from reservoir to pump is filled.
6. Disconnect the pump from all control input signals.

After start-up the oil level in the reservoir may drop due to filling of the system components. Check the level in the reservoir to maintain a full oil level throughout start-up.

Warning

Damage to hydraulic components may occur if you fail to maintain the oil supply.

7. Use a common method to disable the engine to prevent it from starting. Crank the starter for several seconds. Do not to exceed the engine manufacturer's recommendation. Wait 30 seconds and then crank the engine a second time as stated above. This operation helps remove air from the system lines. Refill the reservoir to recommended full oil level.
8. Check the pressure gauge at M3. When charge pressure begins to build, enable and start engine. Let the engine run for a minimum of 30 seconds at low idle to allow the air to work itself out of the system. Check for leaks at all line connections and listen for cavitation. Check for proper fluid level in reservoir.

Caution

Air entrapment in oil under high pressure may damage hydraulic components. Do not run at maximum pressure until system is free of air and fluid has been thoroughly filtered.

9. When the pump establishes adequate charge pressure (as shown in model code), increase engine speed to normal operating rpm to further purge residual air from the system.
10. Shut off engine. Connect pump control signal. Start engine, checking to be certain pump remains in neutral. Run engine at normal operating speed and carefully check for forward and reverse control operation.
11. Continue to cycle between forward and reverse for at least five minutes to bleed all air and flush system contaminants out of loop.

Normal charge pressure fluctuation may occur during forward and reverse operation.

12. Check that the reservoir is full. Remove charge pressure gauge. Re-intall charge pressure plug. The pump is now ready for operation.

Required tools and pressure measurements

Required tools

The service procedures described in this manual can be performed using common mechanic's hand tools. Special tools, if required, are shown. When testing system pressures, calibrate pressure gauges frequently to ensure accuracy. Use snubbers to protect gauges.

Port locations and gauge installation

The following tables and drawing show the port locations and gauge sizes needed.

Port information

Port identifier	Port size	Wrench size	Pressure obtained	Gauge size, bar [psi]
L1, L2	1-1/16 12 SAE	9/16 internal hex	Case drain	10 [150]
MA, MB	9/16 18 SAE	11/16 hex	System pressure	600 [9,000]
M3	9/16 18 UNF	11/16 hex	Charge pressure	50 [750]
M4, M5	9/16 18 SAE	11/16 hex	Servo pressure	50 [750]

System valves


Port identifier	Relief	Port size	Wrench size
RA	A port pressure relief valve	1-5/16 12 UNF	1-1/4 hex
RB	B port pressure relief valve	1-5/16 12 UNF	1-1/4 hex
R	Charge pressure relief valve	3/4 16 UNF	7/8 hex
BP	Bypass valve	5/8 18 UNF	1 inch hex

System ports

Port identifier	Port size
A system pressure port	1-5/16 12 SAE
B system pressure port	1-5/16 12 SAE
S (charge pressure inlet)	1-5/16 12 SAE

Required tools and pressure measurements

Port locations



Troubleshooting

Overview

This section provides general steps to follow if undesirable system conditions occur. Follow these steps until you solve the problem. Some of the items are system specific. For areas this manual covers, we reference the section. Always observe the safety precautions in [Introduction](#) on page 5 and those related to your specific equipment.

Safety precautions

! Caution

High inlet vacuum causes cavitation which can damage internal pump components. Ensure charge pump supply plumbing is adequate. Locating pump below the level of the reservoir, when possible, improves inlet conditions.

! Caution

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines

System noise or vibration

Item	Description	Action
Reservoir oil level	Low oil level leads to cavitation.	Fill reservoir.
Aeration of the oil/pump inlet vacuum	Air in system decreases efficiency of units and controls. Excessive noise, foaming oil, and heat may indicate air in system.	Find location where air is entering into the system and repair leak. Check that inlet line is not restricted and is the proper size.
Cold oil	Cold oil may be too viscous for proper function: pump cavitates.	Allow the oil to warm up to it's normal operating temperature with engine at idle speed.
Pump inlet vacuum	High inlet vacuum causes noise/cavitation.	Check that inlet line is not restricted and is the proper size. Check filter and bypass valve.
Shaft couplings	A loose shaft coupling causes excessive noise.	Replace loose shaft coupling. Replace pump shaft.
Shaft alignment	Misaligned shafts creates noise.	Align shafts.
Charge/system relief valves	Unusual noise may indicate sticking valves, possible contamination.	Clean/replace valves and test pump. May be a normal condition.

System operating hot

Item	Description	Action
Oil level in reservoir	Insufficient hydraulic fluid will not meet the cooling demands of system.	Fill the reservoir to the proper level with clean hydraulic oil.
Heat exchanger (if equipped)	The heat exchanger is not sufficiently cooling the system.	Check the air flow and input air temperature for the heat exchanger. Clean, repair, or replace the heat exchanger as necessary.
Heat exchanger bypass valve	A partially activated heat exchanger bypass valve may result in heat generation within the system.	Verify that the bypass valve is fully closed and that the valve is seating properly. Repair or replace as necessary.
SCR (System Check / Relief) Valves	A partially activated SCR valve or SCR valves with relief settings too low may generate heat within the system.	Verify that the SCR valve is seating properly and is at the correct relief setting. Repair or replace it as necessary.

Troubleshooting

Item	Description	Action
Oil filters	Clogged oil filters may result in an insufficient supply of cool oil to the system.	Inspect the oil filters and verify that they are still operable. Replace them if necessary.
Machine load	Excessive loads or extreme duty cycles can result in the pump and/or motor operating at speeds and pressures beyond system design limitations.	Verify that the machine is operating within the parameters for which it was designed. If necessary, reduce the load on the machine.

System will not operate in one direction

Item	Description	Action
Input control signal (linkage, current, or pressure)	A faulty control signal is being received at the pump. (MDC - binding or broken linkage, EDC - faulty or inadequate electrical signal, HDC - blocked or incorrectly orificed control lines).	Verify that the input signal being received is correct and identical in both directions. Adjust, clean, repair, or replace the control module as necessary.
Displacement limiters (if equipped)	The displacement limiters may be improperly adjusted such that the servo piston is prevented from moving in one direction.	Verify that the displacement limiters are adjusted properly.
SCR (system check / relief) valves	The SCR valves are malfunctioning or improperly set.	Verify that the SCR valves are operating properly. Repair or replace them as necessary.
Pump control	A damaged or biased pump control may be sending a signal commanding the pump to stroke only in one direction.	Verify that the pump's control is functioning properly. Repair or replace it as necessary.
Servo pressure	The drain or supply path to one side of the servo piston may be blocked.	Verify that the servo supply and drain paths are unobstructed and that each orifice is of the correct size and free of debris. Clean or repair them as necessary.

System will not operate in either direction

Item	Description	Action
Oil level in reservoir	There is insufficient hydraulic fluid to supply the system loop.	Fill the reservoir to the proper level with clean hydraulic oil.
Displacement limiters	Displacement limiters may be improperly adjusted such that the servo piston is locked in place.	Verify that the displacement limiters are adjusted to the proper setting.
Input control signal (linkage, current, or pressure)	A faulty control signal being received at the pump. (MDC - binding or broken linkage, EDC - faulty or inadequate electrical signal, HDC - blocked or incorrectly orificed control lines)	Verify that the input signal being received is correct and identical in both directions. Adjust, clean, repair, or replace the input device as necessary.
Oil filters	Clogged oil filters may result in an insufficient supply of oil to the system.	Inspect the oil filters and verify that they are still serviceable. Replace them as necessary.
Bypass valve	A partially activated bypass valve (one or both) may result in a cross port leakage.	Verify that the bypass valves are closed and that the valves are seating properly. Clean, repair, or replace them as necessary.
Charge pressure (in neutral)	Charge pressure may be insufficient to recharge the system loop.	Inspect the charge pump for damage and verify that the charge pressure relief valve is at the proper setting. Repair or replace it as necessary.
Charge pressure (in stroke)	There is low charge pressure resulting from internal leakage within the system.	Repair or replace the component or components within the system causing the internal leakage.
Servo pressure	There is an insufficient pressure differential across the servo piston.	Check servo pressures to verify sufficient pressure delta. Verify that the servo supply and drain paths are unobstructed and that each orifice is of the correct size and free of debris. Clean, repair, or replace them as necessary.

Troubleshooting

Item	Description	Action
Charge pump	The charge pump is damaged or has been installed with the incorrect rotational orientation.	Verify that the charge pump is in good working order and that it is correctly installed. Repair or replace it as necessary.
SCR (system check / relief) valves	The SCR valves are malfunctioning or improperly set.	Verify that the SCR valves are operating and properly set. Repair or replace them as necessary.

Neutral difficult or impossible to find

Item	Description	Action
Input control signal (linkage, current, or pressure)	A faulty control signal is being received at the pump. (MDC - binding or broken linkage, EDC - faulty or inadequate electrical signal, HDC - blocked or incorrectly orificed control lines)	Verify that the input signal being received is correct and identical in both directions. Adjust, clean, repair, or replace control module as necessary.
System pressure	With no input signal to the control, a pressure delta may exist between the two sides of the working loop.	Readjust pump neutral setting. Refer to Swashplate neutral adjustment on page 22.
Servo pressure	With no input signal to the control, a pressure delta may exist across the servo piston.	Readjust the control neutral setting. Refer to Manual Displacement Control Neutral-Return Bracket Adjustment on page 23 and Electric Displacement Control/Hydraulic Displacement Control Neutral Adjustment on page 24
PCP pressure (EDCs only)	With no input signal to the control, a pressure difference may exist across the control spool.	Replace the EDC.

System response is sluggish

Item	Description	Action
Reservoir oil level	There is an insufficient amount of hydraulic fluid, resulting in an inadequate supply for the system loop.	Fill the reservoir to the proper level with clean hydraulic fluid.
Input control signal (linkage, current, or pressure)	A faulty control signal is being received at the pump. (MDC - binding or broken linkage; EDC - faulty or inadequate electrical signal; HDC - blocked or incorrectly orificed control lines)	Verify that the input signal being received is correct and identical in both directions.
Pump control	A damaged pump control or control spool will not correctly transmit the control input signal to the pump.	Verify that the pump's control is operating properly and that the control spool is not damaged or worn and moves freely within its bore. Clean, repair, or replace it as necessary.
Bypass valve	A partially activated bypass valve causes cross port leakage.	Verify that the bypass valve is closed and that the valve is seating properly. Clean, repair, or replace it as necessary.
SCR (system check / relief) valves	One or both of the SCR valves may be binding within their bores.	Verify that the SCR valves operate freely. Repair or replace them as necessary.
Charge pressure (in neutral)	There is low charge pressure resulting from a damaged charge pump or low charge pressure relief valve setting.	Inspect the charge pump for damage and verify the charge pressure relief valve setting. Repair or replace as necessary.
Charge pressure (in stroke)	There is low charge pressure resulting from internal leakage within the system.	Repair or replace the component or components within the system causing the internal leakage.

Troubleshooting

Item	Description	Action
Servo pressure	There is insufficient pressure differential across the servo piston.	Check servo pressures at port M4 and M5 to verify sufficient pressure delta. Verify that the servo supply and drain paths are unobstructed and that each orifice is of the correct size and free of debris. Clean, repair, or replace as necessary.
Charge pump	The charge pump has been damaged or installed with the incorrect rotational orientation.	Verify that the charge pump is in good working order and that it is correctly installed. Repair or replace it as necessary.

Electrical troubleshooting

Item	Description	Action
Control operates pump in one direction only	Control coil had failed (EDC).	Measure resistance at coil pins. Resistance should be 14.20 ohms (24V) or 3.66 ohms (12V) at 20°C [70°F]. Replace coil.
No pump function	No power to controller.	Restore power to controller.
Erratic pump function	Electrical connection to pump is bad.	Disconnect connection, check wires, reconnect wires.
Filter bypass indicator switch	Filter switch may be bad.	Check/replace filter switch. Add gauge to filter bypass port to verify proper fluid flow and verify switch operation by measuring resistance. open resistance=>510 ohms, closed resistance<=122 ohms.

Adjustments

Standard procedures, inspections, and adjustments

Before working on the pump, clean all dirt and grime from the outside of the pump and surrounding area.

Caution

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.

1. If removing the pump, tag each hydraulic line. If you disconnect hydraulic lines, plug each open port to ensure that dirt and contamination do not get into the pump.
2. Inspect the hydraulic fluid for signs of system contamination, oil discoloration, foam in the oil, sludge, or small metal particles.
3. If there are signs of contamination in the hydraulic fluid, replace all filters and drain and clean the hydraulic system. Fill with the correct hydraulic fluid.
4. Flush the lines before replacing the hydraulic fluid.
5. Before re-installing the pump, test for leaks.

Warranty

Performing installation, maintenance, and minor repairs according to the procedures in this manual will not affect your warranty. Major repairs requiring the removal of a unit's front flange voids the warranty unless done by a Danfoss Global Service Partner.

Pump adjustment

This section offers instruction on adjustment of pump components. Read through the entire topic before beginning a service activity. Refer to [Port locations and gauge installation](#) on page 12, for location of gauge ports and suggested gauge size.

Charge pressure relief valve


This procedure explains how to check and adjust the charge pressure relief valve.

1. Install a 50 bar [1000 psi] pressure gauge in charge pressure gauge port M3. Install a 10 bar [100 psi] gauge in one of the case pressure ports L1 or L2. Operate the system with the pump in neutral (zero displacement) when measuring charge pressure.
2. To adjust charge pressure, shut down system.
3. Using a 1 inch hex wrench, remove charge pressure relief plug (102). Add or remove shims (101) in relief valve. Adding shims increases charge pressure, while removing shims decreases charge pressure.
4. Lubricate and install new O-ring (103).
5. Using a 1 inch hex wrench, reinstall plug. Torque to 108 N·m [80 lbf·ft].
6. Operate pump in neutral to verify proper charge setting. Charge pressure is referenced to case pressure. Subtract case pressure (L1/L2) from charge pressure (M3) to compute actual setting. Repeat steps 1-5 if necessary.

Adjustments

7. Remove gages and replace plugs (M3, L1/L2). Using an 11/16 in. hex wrench, torque plug (M3) to 37 N·m [27 lbf·ft]. Using a 9/16 in. internal hex wrench, torque plug (L1/L2) to 115 N·m [85 lbf·ft].

Charge pressure adjustment



Engaging the bypass function

Test the bypass function with the pump installed on the machine. The bypass function is engaged by unscrewing the bypass valve. Do not open the bypass valve when the machine is operating.


1. To engage the bypass function, use a 5/8 in. hex wrench to unthread the bypass valve. Rotate the bypass valve approximately three turns counterclockwise. Do not rotate more than 3 revolutions: additional rotation permits external leakage.
2. To close the bypass valve, rotate the bypass valve clockwise until seated. Torque to 20 N·m [15 lbf·ft].
3. Vehicle/machine should move with bypass valve open. Close valve for normal operation.

Caution

Bypass valve is not a tow-valve. Damage to pump and motor is possible when operating without charge pressure. Limit speed of movement to 20% of the vehicle/machine's maximum for no longer than 3 minutes.

Adjustments

Using the bypass function



P106 633E

System check/relief (SCR) valves

The SCR valve is a high pressure relief valve and a system check valve in combination. Whenever an SCR valve is replaced or opened, operate the pump in its full range of functions to ensure proper machine operation. The SCR valves are pre-set at the factory, no adjustment is possible. Pressure code is marked on the valve. Refer to the model code for pressure designation. If you suspect SCR malfunction, replace valve and test operation of pump.


This procedure explains how to replace the SCR valves.

1. Shut down the system.
2. Using a 1-1/4 in. hex wrench, remove relief valve plug (166).
3. Remove spring (165) and relief valve (1103) from pump housing.
4. Insert new relief valve and spring into pump housing.
5. Lubricate and install new O-ring (106).

Adjustments

6. Using a 1-1/4 in. hex wrench, install relief valve plug. Torque to 176 N·m [130 lbf·ft].

Installing the SCRs



Displacement limiter adjustment


Pump may have a displacement limiter on each side of the servo. Each limiter may be adjusted to a different setting.

1. Remove snap ring (928) and sleeve (929).
2. Using a flat screw driver to hold the displacement limiter, loosen the locking nut (927) with a 9/16 hex wrench.
3. Rotate the displacement limiter (911) to adjust maximum displacement. Rotating the adjusting screw clockwise decreases the maximum displacement of the pump while rotating the adjusting screw counterclockwise increases the maximum displacement. The displacement changes approximately 4 cm³ per revolution.
4. After establishing the desired maximum displacement setting, hold displacement limiter in place using a flat screw driver and tighten the locking nut with a 9/16 in. hex wrench. Torque to 19 N·m [14 lbf·ft]. Repeat if necessary to adjust maximum displacement in other direction.

Adjustments

5. After adjustment, verify proper maximum vehicle/machine speed. Readjust if necessary.

Displacement limiter adjustment



Swashplate neutral adjustment

With the pump properly plumbed, primed, and mounted on a vehicle or test stand, use this procedure to adjust mechanical neutral. If pump is on a vehicle, securely block the wheels to prevent movement.

Measured data

- System pressure at MA
- System pressure at MB
- Pressure differential between MA and MB (optional)

Pump Setup


1. Attach 600 bar [10,000 psi] gauge to system pressure gage ports MA and MB.
2. Using a hydraulic line and fittings, shunt the servo piston by connecting servo pressure ports (M4 and M5).

Connecting servo ports M4 and M5 defeats the affect of any control pressure on the servo piston.

Adjustments

3. Run prime mover at normal operating speed.
4. Use a 1/4 hex wrench to hold adjusting screw (908) in place and a 9/16 hex wrench to loosen servo lock nut (115).
5. Turn neutral adjustment screw (908) until one system pressure gage begins to show an increase in pressure. Note position of screw. Turn the neutral adjustment screw (908) in the opposite direction until the other system pressure gage begins to show an increase in pressure. Note position of screw. Turn the neutral adjustment screw half way between the two positions.
6. Use a 1/4 hex wrench to hold the servo adjustment screw in place, and a 9/16 hex wrench to tighten servo lock nut (115). Torque to 37 N·m [27 lbf·ft].
7. Shut down prime mover and remove previously installed gauges and fittings. Plug ports MA, MB, M4, and M5.

Servo neutral adjustment



Manual Displacement Control Neutral-Return Bracket Adjustment

With the pump properly plumbed, primed, and mounted on a vehicle or test stand, use the following procedure to adjust the pump displacement control to neutral position. If pump is on a vehicle, securely block the wheels to prevent movement. Check swashplate mechanical neutral adjustment before adjusting control bracket. Refer to previous topic [Swashplate neutral adjustment](#) on page 22 for instructions. If swashplate neutral is properly adjusted and system is not in neutral, adjust MDC bracket as described below.

Measured data

- Servo pressure at M4
- Servo pressure at M5
- Pressure differential between M4 and M5 (optional)

Procedure


1. Attach 20 bar [300 psi] gauge to each servo gage port M4 and M5. Run prime mover at normal operating speed.
2. Using a 3/8 in. hex wrench, loosen screw (1210) allowing the neutral bracket to move, but not freely.
3. Start prime mover and slowly accelerate to normal operating rpm.
4. Using your hand, press neutral bracket towards the pump housing, and rotate it until one of the servo pressure gages indicates an increase in pressure. Note position of bracket. Rotate neutral bracket in

Adjustments

opposite direction until the other servo pressure gage indicates an increase in pressure. Note position of bracket. Rotate neutral bracket half way between the two positions.

5. Holding the neutral adjustment bracket in place, use a 3/8 in. hex wrench to tighten screw (1210). Torque to 14 N•m [10 lbf•ft].
6. Shut down prime mover and remove previously installed gauges. Plug ports M4, M5. Torque to 37 N•m [27 lbf•ft]

Manual displacement control bracket adjustment



P106 631E

Electric Displacement Control/Hydraulic Displacement Control Neutral Adjustment

With the pump properly plumbed, primed, and mounted on a vehicle or test stand, use this procedure to adjust the pump displacement control to neutral position. If pump is on a vehicle, block the wheels to prevent movement.

Measured data

- Servo pressure at M4
- Servo pressure at M5
- Pressure differential between M4 and M5 (optional)


Procedure

1. Attach 20 bar [300 psi] gauge to each servo gage port.
2. Use a 5/32in. internal hex wrench to hold the adjusting screw in place and a 1/2 hex wrench, loosen locknut.
3. Start prime mover and slowly accelerate to normal operating rpm.
4. Rotate adjustment screw until one of the servo pressure gages indicates an increase in pressure. Note position of screw. Rotate adjustment screw in opposite direction until the other servo pressure gage indicates an increase in pressure. Note position of screw. Rotate adjustment screw halfway between the two positions.
5. While holding the neutral adjustment screw in place, tighten locknut. Torque to 3 N•m [27 lbf•in].

Adjustments

- 6.** Stop prime mover and remove previously installed gauges. Plug ports M4, M5. Torque to 37 N•m [27 lbf•ft]

EDC / HDC control adjustment



HC EDC Control

Control neutral adjustment

All functions of the Electric Displacement Control (EDC), are preset at the factory. If necessary, adjust the pump to neutral with the pump running on a test stand or on the vehicle/machine with the prime mover operating. If adjustment fails to give satisfactory results, you may need to replace the control or coils. See Minor repair for details.

Warning

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable/disconnect the mechanism while servicing.


1. Install a 50 bar [1000 psi] gauge in each of the two servo gauge ports (M4 and M5). Disconnect the external control input (electrical connections) from the control. Start the prime mover and operate at normal speed.
2. Use a 4mm internal hex wrench to hold the neutral adjusting screw (D015) stationary while loosening the locknut (D060) with a 13mm wrench.

Adjustments

3. Observe pressure gauges. If necessary, turn adjusting screw (D015) to reduce pressure differential.

EDC adjustment is very sensitive. Be sure to hold the hex wrench steady while loosening the locknut. Total adjustment is less than 120 degrees.

Control Adjustment



P108773

4. Rotate the neutral adjusting screw (D015) clockwise until the pressure increases on the gauge. Note the angular position of the wrench. Then rotate the neutral adjusting screw counterclockwise until the pressure increases by an equal amount on the other gauge. Again note the angular position of the wrench.
5. Rotate the neutral adjusting screw clockwise half the distance between the wrench positions noted above. The gauges should read the same pressure, indicating that the control is in its neutral position.
6. Hold the neutral adjusting screw stationary and tighten the locknut (D060). Torque to 12 N·m [9 lbf·ft]. Do not over torque the nut.
7. When the neutral position is set, stop the prime mover, remove the gauges, and install the gauge port plugs. Reconnect the external control input.

A small pressure differential of 1.5 bar [22 psi] or less is acceptable. Zero differential is usually not possible.

Adjustments

Neutral Adjustment (EDC) (bottom view)




Illustration shows how cam on adjusting pin rotates to adjust for neutral position after pump is re-installed.

Minor repair

Standard procedures, removing the pump

Before working on the pump, clean all dirt and grime from the outside.

If the pump has an auxiliary pump attached, remove both pumps as a single unit. Tag all hydraulic lines as they are disconnected and plug all open ports to ensure that dirt and contamination do not get into the pump.

Caution

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.

Removal

1. With the prime mover off, thoroughly clean all dirt and grime from the outside of the pump.
2. Tag and disconnect each hydraulic line connected to the pump. As hydraulic lines are disconnected, plug each open port, to ensure that dirt and contamination do not get into the pump.
3. Remove the pump and its auxiliary pump (if applicable) as a single unit.

Caution

Be careful not to damage solenoids and electrical connections when using straps or chains to remove pump from machine.

Inspection

1. Ensure the work surface and surrounding area are clean and free of contaminants such as dirt and grime.
2. Inspect the hydraulic fluid for signs of system contamination, oil discoloration, foam in the oil, sludge, or small metal particles.

Reassembly

1. Before replacing the pump on the machine, replace all filters and drain the hydraulic system. Fill the system with the correct, filtered, hydraulic fluid.
2. Flush the lines before replacing the hydraulic fluid.

For repair part information, see *Danfoss publication Series 40 M46 Variable Pump Parts Manual BLN-2-41701* for your model.

Displacement limiter

Removal

Only remove displacement limiter (911) if replacement is necessary. Mark the location of displacement adjustment and neutral adjustment screws before disassembly. This saves time during re-assembly.

1. Remove snap ring (928) and sleeve (929). Use a 1/4 in. hex wrench to hold neutral adjustment screw in place. Use a 9/16 in. hex wrench to remove hex nut (115).
2. Use a flat screw driver to hold displacement limiter (911) in place. Use a 9/16 in. hex wrench to remove lock nut (927).
3. Using a 3/8 in. hex wrench, remove five bolts (921) from servo cover (902).
4. Unscrew servo cover (902) to remove it from neutral adjustment screw. Remove and discard gasket (936).
5. Turn displacement limiter (911) out of servo cover (902).

Minor repair


Inspection

Inspect all parts for damage. Inspect the mating surfaces of the servo cover (902) and pump housing for scratches, grooves, and other damage. Inspect threads of screws and nuts for damage. Replace any damaged parts.

Reassembly

1. Turn displacement limiter (911) into servo cover (902). Install new gasket (936) and turn servo cover (902) onto neutral adjustment screw.
2. Using a 3/8 in. hex wrench, install five bolts (921). Torque to 15 N·m [11 lbf·ft].
3. Adjust displacement limiter to position originally noted during disassembly. Use a flat screw driver to hold displacement limiter. Use a 9/16 in. hex wrench to install seal nut (927) onto displacement limiter (911). Torque to 19 N·m [14 lbf·ft].
4. Set neutral adjustment screw at the position noted during disassembly. Use a 1/4 in. hex wrench to hold neutral adjustment screw and a 9/16 in. hex wrench to install hex nut (115). Torque to 37 N·m [27 lbf·ft]. Install sleeve (929) and snap ring (928).

Displacement limiter removal/installation



Pressure filtration adapter

Removal

1. Using an 11/16 in. hex wrench, remove plug (810). Remove and discard O-ring (810A).
2. Using a 1/2 in. hex wrench, remove screws (806).
3. Remove pressure filtration cover (801). Remove and discard seal adapter (805).

Inspection

Inspect the machined surface on the control. If any nicks or scratches are found, replace the damaged component.


Reassembly

1. Install new seal adapter (805) and filtration cover (801).
2. Using a 1/2 hex wrench, install three screws (806). Torque to 30 N·m [22 lbf·ft].

Minor repair

3. Lubricate and install O-ring (810A) onto plug (810). Using an 11/16 in. hex wrench, install plug (810). Torque to 37 N·m [27 lbf·ft].

Pressure filtration adapter removal/installation



Charge pump

Removal


If a gear pump is attached to the auxiliary pad, remove the gear pump and O-ring or gasket.

1. Using a 9/16 in. hex wrench, remove screws (1506) and cover plate (1505). Remove and discard seal (1504).
2. Using a 9/16 in. hex wrench, remove screws (1502). Remove auxiliary pad (1503).
3. Remove and discard O-ring (141) and load ring (142).
4. Remove gerotor cover (155) and gerotor (603).

Minor repair

5. Remove pin (604) and key (605).

Charge pump removal/installation



Inspection

Inspect the gerotor (603) and gerotor cover (155) for wear, scratches or pitting. If any component shows signs of wear, scratching, or pitting, replace all components. Inspect pin (604) and key (605) for damage, and replace parts if necessary. Replace O-ring (141), load ring (142), and seal (1504) whenever charge pump is disassembled.

Reassembly

[Charge pump parts are available as a complete set](#)

1. Install key (605). Lubricate and install gerotor assembly (603).
2. Install pin (604) and gerotor cover (155).
3. Lubricate and install new O-ring (141) and load ring (142). Install auxiliary pad (1503).

Minor repair

4. Using a 9/16 in. hex wrench, install screws (1502). Torque to 43 N•m [32 lb•ft].
5. Lubricate and press seal (1504) onto auxiliary pad (1503).

If a gear pump is attached to the auxiliary pad, install a new O-ring or gasket and gear pump

6. Install cover plate (1505). Using a 9/16 in. hex wrench, install capscrews (1506). Torque to 30 N•m [22 lbf•ft].

If a gear pump is attached, seal (1504), cover (1505), and bolts (1506) are not used. Replace O-ring or gasket between gear pump and M46 pump.

Shaft seal, roller bearing and shaft replacement

The shaft assembly is serviceable without removing the front cover of the pump, but the charge pump must be removed first. Orient the pump on the work surface so the shaft is pointing up with the charge pump (603) and key (605) removed from shaft. See [Charge pump](#) on page 30

Removal

1. Using a snap-ring pliers, remove snap-ring (132) from pump cover. Remove and discard seal (301). Remove second snap-ring (132).
2. Remove shaft assembly from pump cover.

Caution


Do not damage the housing bore, shaft, or bearing when removing the shaft and shaft seal.

3. Using a snap ring pliers, remove both snap-rings (133). Press bearing (131) off of shaft.

Caution

Do not rotate or move pump after removing shaft. Internal components may be dislodged making shaft replacement impossible without complete disassembly.

Shaft assembly



Minor repair


Inspection

Inspect the shaft and bearing for wear, scratching and pits. If wear, scratching or pitting is found, replace the shaft and bearing. Rotate bearing while feeling for roughness. Replace bearing if it doesn't spin freely.

Reassembly

1. Using a snap ring pliers, install snap-ring (133). Lubricate and press bearing (131) onto shaft. Install second snap-ring (133).
2. Install shaft and bearing assembly into front cover. Rotate shaft to align with block-splines. Ensure bearing is installed deep enough to clear snapping groove.
3. Using a snap ring pliers, install snapping (132).
4. Cover shaft splines with an installation sleeve to protect lipseal during installation. Lubricate and press new seal (301) into pump cover.
5. Install second snap-ring (132). Remove installation sleeve.

Shaft seal installation tool



SCR valves

The SCR valves are factory set and are not field adjustable.

Removal

1. Using a 1-1/4 in. hex wrench, remove relief valve plug (166). Remove and discard Oring (106).
2. Remove spring (165) and relief valve (1103) from pump housing.

Inspection

Inspect the sealing surfaces of the pump for nicks or scratches. Inspect the relief valve (1103) sealing surface for nicks or scratches. If the relief valve (1103) is damaged, replace it.


Reassembly

1. Lubricate and insert relief valve (1103) and spring (165) into pump housing.

Minor repair

2. Lubricate and install new O-ring (106) onto plug (166). Using a 1-1/4 in. hex wrench install relief valve plug (166). Torque to 176 N·m [130 lbf·ft].

SCR valves



Charge pressure relief valve

Replace the charge pressure relief valve components if they are damaged or if you suspect failure. See [Charge pressure relief valve](#) on page 18, for adjustment instructions.

Removal

1. Using a 1 inch hex wrench, remove charge pressure relief plug (102). Remove and discard O-ring (103).
2. Remove shims (101), spring (104), and charge pressure relief valve (105).

Inspection

Inspect the sealing surfaces of the pump for nicks or scratches. Inspect the relief valve (105) sealing surface for nicks or scratches. If the relief valve (105) is damaged, replace it.


Reassembly

1. Install charge pressure relief valve, spring, and shims.
2. Lubricate and install O-ring onto plug. Using a 1 in. hex wrench, install plug. Torque to 108 N·m [80 lbf·ft].

Minor repair

3. Operate pump at full range of controls to ensure proper machine operation.

Charge pressure relief valve



Bypass valve

Removal

1. Using a 5/8 in. hex wrench, remove bypass valve (1001).
2. Remove and discard O-ring (1003) and backup ring (1002).

Inspection

Inspect the sealing surfaces of the pump for nicks or scratches. Inspect the bypass valve (1001) sealing surface for nicks or scratches. Replace any damaged parts.


Reassembly

1. Lubricate and install new O-ring (1003) and backup ring (1002) onto bypass valve (1001).
2. Using a 5/8 in. hex wrench, install bypass valve (1001). Torque to 20 N·m [15 lbf·ft].

Minor repair

3. Operate pump at full range of controls to ensure proper machine operation.

Bypass valve



Manual displacement control

Removal

1. Using a 3/8 in. hex wrench, remove screw (1210). Remove manual control spool assembly from pump housing.
2. Using a 1/2 in. hex wrench, remove lock nut (1213). Remove lock washer (1235), handle (1215), neutral return bracket (1216), and spring (1214) from spool (1207).

Mark the location of neutral return bracket (1216) before disassembly.

3. Remove and discard backup ring (1209) and O-ring (303) from spool.
4. Remove sleeve (1402). Remove and discard backup ring (1208) and O-ring (302).

Inspection

Inspect all parts of control assembly. Replace any damaged parts. Inspect spool and sleeve for grooves, scratches, and other damage. If spools are damaged, replace them. Inspect sleeve bore in housing for damage.

Reassembly


1. Lubricate and install O-ring (302) and backup ring (1208) onto sleeve (1402). Lubricate and install sleeve (1402) into motor housing.

When installing sleeve (1402), ensure that sleeve groove engages spring pin on swashplate.

2. Lubricate and install O-ring (303) and backup ring (1209) onto spool (1207).


Install control spool (1207) with alignment slot facing servo piston.

Minor repair



3. Install neutral return spring (1214), neutral return bracket (1216), handle (1215), and washer (1235) onto spool (1207).
4. Using a 1/2 in. hex wrench, install lock nut (1213). Torque to 15 N·m [11 lbf·ft].
5. Lubricate and install spool (1207) into sleeve (1402).
6. Using a 3/8 in. hex wrench, install screw (1210). Torque to 14 N·m [10 lbf·ft]. See [Manual Displacement Control Neutral-Return Bracket Adjustment](#) on page 23, for adjustment procedure.

Manual displacement control



Electronic displacement control/hydraulic displacement control

Removal

If you suspect control of failure, replace control and test pump for proper operation. When installing control, ensure that sleeve groove engages spring pin on swashplate.

Minor repair

1. Using a 3/16 in. internal hex wrench, remove screws (1203 and 1204) or (1224). If you have a three position controll, remove screws (1226) using a 4 mm internal hex wrench.
2. Remove control housing (1201) or manifold (1225). Remove and discard O-rings (1220 and 304) or (1227, 1228, and 1223A).

Inspection

Inspect control spool for scratches, grooves, and other damage. If spool is damaged, or you suspect control malfunction, replace entire control unit. Inspect sleeve bore in housing for damage.


Reassembly

1. Lubricate and install O-rings (1220 and 304) onto control housing (1201) or for a three position control, lubricate and install O-rings(1227 and 1228) onto manifold (1225) and O-rings (1229) onto control housing (1223). Install control housing (1201) or manifold (1225) onto pump housing, align sleeve groove with spring pin on swashplate.

Minor repair

2. If you have a three position control, use a 4 mm internal hex wrench to install screws (1226). Torque screws to 14 N·m [10 lbf·ft]. Install three position control housing (1223). Using a 3/16 in. internal hex wrench, install screws (1203 and 1204) or (1224). Torque to 14 N·m [10 lbf·ft].

EDC / HDC repair



MDC orifice repair

Removal

1. Using a 3/16 in. internal hex wrench, remove pipe plug (1219).
2. Using a 1/8 in. internal hex wrench, remove filter or orifice plug (1401).

Inspection

Clean orifice. Replace if necessary.


Reassembly

1. Using a 1/8 in. internal hex wrench, install filter or orifice plug (1401). Torque to 3 N·m [2 lbf·ft].
2. Using a 3/16 in. internal hex wrench, install pipe plug (1219). Torque to 22 N·m [16 lbf·ft].

Install Pipe plug (1219) with thread lock. Apply a few drops before installation.

Minor repair

MDC orifice repair



EDC/HDC orifice repair

Removal

1. Remove servo covers. See [Displacement limiter](#) on page 28, for servo cover removal and installation instructions.
2. Using a 7/32 in. internal hex wrench, remove orifice plugs (1403 and 1404).

Inspection

Clean orifice. Replace if necessary.


Reassembly

1. Using a 7/32 in. internal hex wrench, install orifice plugs (1403 and 1404). Torque to 3 N•m [2 lbf•ft].

Minor repair

2. Install servo covers. See [Displacement limiter](#) on page 28, for servo cover removal and installation instructions.

EDC/HDC orifice repair



HC EDC Control Repair


1. Using a 5 mm internal hex wrench, remove the six cap screws (D250).
2. Remove the control module and gasket (D150). Discard the gasket.
3. Inspect the machined surfaces on the control and top of the pump. If you find any nicks or scratches, replace the component.
4. Install a new gasket (D150).

Ensure that you install the dowel pins (D300) in the housing before installing the control.

Minor repair

5. If you removed screen (D084), install a new one. Install with the mesh facing outward (see drawing).

Proper screen orientation




6. Install the control module and six cap screws (D250).

Remove plug on top of control to ensure the swashplate feedback pin is properly positioned in the center of the control module when installing control.


Minor repair

7. Using a 5 mm internal hex wrench, torque the cap screws (D250) to 13.5 N·m [10 lbf·ft].

HC ECD Control



Torque sequence



Torque chart

Fastener size and torque chart


Item	Fastener	Wrench size	Torque
920	Servo piston cover screws	3/8 hex	15 N•m [11 lbf•ft]
921	Servo piston cover screws	3/8 hex	15 N•m [11 lbf•ft]
130	Front cover screw	T50 Torx	58 N•m [43 lbf•ft]
163	Front cover screws	T55 Torx	91 N•m [67 lbf•ft]
1506	Rear cover screws	9/16 hex	77 N•m [57 lbf•ft]
806	Filtration cover screw	1/2 hex	30 N•m [22 lbf•ft]
115	Lock/seal nut	11/16 hex	37 N•m [27 lbf•ft]
927	Displacement limiter lock/seal nut	9/16 hex	19 N•m [14 lbf•ft]
1213	Control handle nut	1/2 hex	15 N•m [11 lbf•ft]
1210	Screw	3/8	14 N•m [10 lbf•ft]

Plug size and torque chart

Item	O-ring plug	Wrench size	Torque
102	3/4 16 UNF	1 inch hex	108 N•m [80 lbf•ft]
107	1-1/16 12 UNF	9/16 internal hex	115 N•m [85 lbf•ft]
110	9/16 18 UNF	11/16 hex	37 N•m [27 lbf•ft]
111	9/16 18 UNF	11/16 hex	37 N•m [27 lbf•ft]
158	7/16 20 UNF	9/16 hex	20 N•m [15 lbf•ft]
810	9/16 18 UNF	11/16 hex	37 N•m [27 lbf•ft]
1001	5/8 18 UNF	5/8 hex	20 N•m [15 lbf•ft]
1101	1-5/16 12 UNF	1-1/4 hex	176 N•m [130 lbf•ft]
1102	1-5/16 12 UNF	1-1/4 hex	176 N•m [130 lbf•ft]

Torque chart

Hardware locations



Products we offer:

- Bent Axis Motors
- Closed Circuit Axial Piston Pumps and Motors
- Displays
- Electrohydraulic Power Steering
- Electrohydraulics
- Hydraulic Power Steering
- Integrated Systems
- Joysticks and Control Handles
- Microcontrollers and Software
- Open Circuit Axial Piston Pumps
- Orbital Motors
- PLUS+1® GUIDE
- Proportional Valves
- Sensors
- Steering
- Transit Mixer Drives

Danfoss Power Solutions is a global manufacturer and supplier of high-quality hydraulic and electronic components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market. Building on our extensive applications expertise, we work closely with our customers to ensure exceptional performance for a broad range of off-highway vehicles.

We help OEMs around the world speed up system development, reduce costs and bring vehicles to market faster.

Danfoss – Your Strongest Partner in Mobile Hydraulics.

Go to www.powersolutions.danfoss.com for further product information.

Wherever off-highway vehicles are at work, so is Danfoss. We offer expert worldwide support for our customers, ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide comprehensive global service for all of our components.

Please contact the Danfoss Power Solution representative nearest you.

Comatrol

www.comatrol.com

Turolla

www.turollaocg.com

Hydro-Gear

www.hydro-gear.com

Daikin-Sauer-Danfoss

www.daikin-sauer-danfoss.com

Local address:

**Danfoss
Power Solutions (US) Company**
2800 East 13th Street
Ames, IA 50010, USA
Phone: +1 515 239 6000

**Danfoss
Power Solutions GmbH & Co. OHG**
Krokamp 35
D-24539 Neumünster, Germany
Phone: +49 4321 871 0

**Danfoss
Power Solutions ApS**
Nordborgvej 81
DK-6430 Nordborg, Denmark
Phone: +45 7488 2222

**Danfoss
Power Solutions Trading
(Shanghai) Co., Ltd.**
Building #22, No. 1000 Jin Hai Rd
Jin Qiao, Pudong New District
Shanghai, China 201206
Phone: +86 21 3418 5200

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.